



Securitron Magnalock Corp.  
Tel 800.624.5625

www.securitron.com  
techsupport@securitron.com

ASSA ABLOY, the global leader  
in door opening solutions

## ZONE LIGHT PANEL INSTRUCTIONS: MODELS ZLP-1, ZLP-2, ZLP-4

The zone light panel comes with pairs of LED's (red and green). It is used to annunciate conditions in a security equipment installation.

The LED's operate on **24VDC as the unit is delivered**. Connect +24v to the yellow wire of each LED and negative to the black wire. **For 12VDC operation**, note that the yellow wire of each LED carries a resistor mounted in line. Cut away and discard the resistor and the LED will operate on 12VDC.